i01898035

## **Control Valve (Blade) - Assemble**

**SMCS -** 5051-016-BG

## **Assembly Procedure**




Illustration 1 g00987538

Note: Check the O-ring seal for wear or for damage. If necessary, replace the O-ring seal.

1. Install O-ring seal (20). Install relief valve (19). Tighten relief valve (19) to a torque of  $74 \pm 5$  N·m (55  $\pm 4$  lb ft).




Illustration 2 g00987536

Note: Check the O-ring seal for wear or for damage. If necessary, replace the O-ring seal.

2. Install O-ring seal (18). Install relief valve (17). Tighten relief valve (17) to a torque of  $74 \pm 5 \text{ N} \cdot \text{m}$  (55  $\pm$  4 lb ft).




Illustration 3

g00987535

Note: Check the O-ring seal for wear or for damage. If necessary, replace the O-ring seal.

3. Install adapter (14). Install O-ring seal (15) and spring seat (16).




Illustration 4

g00987528

4. Install spring (13).



Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.




Illustration 5 g00987526

#### 5. Position cap (12) and install bolts (11).




Illustration 6 g00987524

Note: Check the O-ring seal for wear or for damage. If necessary, replace the O-ring seal.

#### 6. Install O-ring seal (10) and spring seat (9).




Illustration 7 g00987523

7. Install spring (8).



Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.




Illustration 8 g00987522

8. Position cap (7) and install bolts (6).




Illustration 9 g00987518

# **MARNING**

Improper assembly of parts that are spring loaded can cause bodily injury.

To prevent possible injury, follow the established assembly procedure and wear protective equipment.