


# TROUBLE DIAGNOSIS

## Component Parts Location

NHS00010



PHIA1041E


- |   |   |  |
|---|---|--|
| 1. Front passenger air bag module           | 2. Driver air bag module                          | 3. Spiral cable                          |
| 4. Diagnosis sensor unit                    | 5. Side air bag (Satellite) sensor (RH/LH)        | 6. Front seat belt pre-tensioner (RH/LH) |
| 7. Seat belt buckle switches                | 8. Front side air bag modules                     | 9. Side curtain air bag module           |
| 10. Crash zone sensor                       | 11. Belt tension sensor                           | 12. Belt tension sensor connector *      |
| 13. Occupant classification system sensor * | 14. Occupant classification system control unit * |  |

\*: 12, 13, 14 → The bottom of front passenger seat

# TROUBLE DIAGNOSIS

## Schematic

NHS0001P



THWM0267E