



ETN111474CR1

KEY	PART NO.	PART NAME	QTY	REMARKS	
1	H75541	Clamp	7		
2	14M7298	Flange Nut	11	M8	
3	19M7866	Screw	8	M8 X 20	
4	19M7867	Screw	3	M8 X 25	
5	M84309	Push Nut	3		
6	AXE55453	Hydraulic Hose	1		
7	AH96317	Clip	8		

Beater - ST823019 _____	3
Beater Cover Sheet - ST819166 _____	6
Beater Grate - ST824557 _____	8
Beater Grate Limit Curtain - ST824690 _____	11
Beater Seals - ST823169 _____	13
Booster Bar - ST939884 _____	15
Concave Adjuster - ST818609 _____	17
Concave Inserts - ST825818 _____	20
Concave Latch - ST825075 _____	22
Concave Nose - ST825788 _____	24
Concave, High Versatility - ST918513 _____	26
Cylinder Shearbar - ST823963 _____	29
Deawning Plates Adjuster, High Versatility - ST919903 _____	31
Deawning Plates Fixed Adjuster - ST932917 _____	34
Deawning Plates Swing Adjuster - ST932904 _____	37
Full Wire Universal Concave W_ Bolted Concave Nose - ST847737 _	40
Full Wire Universal Concave W_ Fixed Concave Nose - ST939854 _	42
Limit Curtain - ST830123 _____	44
Multi Crop Round Bar Concave Insert, Attachment - ST934811 _____	46
Perforated Filler Plates, Threshing Cylinder - ST826461 _____	48
Plate Concave Stop - ST847824 _____	50
Power Separator, Wide - ST934377 _____	52
Rasp Bar Threshing Cylinder - ST818144 _____	56
Shield W_O Power Separator, Wide Body - ST934396 _____	58
Small Wire Concave W_ Bolted Concave Nose, Small Grains - ST847747 _____	60
Small Wire Concave W_ Fixed Concave Nose, Small Grains - ST939858 _____	62
Straw Walker Crankshaft and Bearings - ST827102 _____	64
Straw Walker Drive Gear Case and Pulley - ST900184 _____	67

Straw Walker W_ Bolted Grids - ST827054 _____	71
Straw Walker Welded W_ Lip Tip Inserts - ST831070 _____	73
Threshing Cylinder Filler Plates - ST826446 _____	75
Threshing Cylinder Filler Plates, Crop Conversion for Rice and Corn , Attachment - ST934795 _____	77