


Record Rear Axle Housing Serial Number



TX1210046A-UN: Rear Axle Housing Serial Number Plate Location

LEGEND:

1 - Rear Axle Serial Number Plate


-: Rear Axle Housing Serial Number

Rear Axle Housing Serial Number:

The rear axle serial number plate (1) is located on the top center of rear axle housing.

JB3888,0000E65-19-20160203

Record Mechanical Front Wheel Drive (MFWD) Front Axle Housing Serial Number—If Equipped



TX1209412A-UN: MFWD Front Axle Housing Serial Number Plate Location

LEGEND:

1 - MFWD Front Axle Serial Number Plate

-: MFWD Front Axle Housing Serial Number

MFWD Front Axle Housing Serial Number:

The mechanical front wheel drive (MFWD) front axle serial number plate (1) is located on the back right side of the axle.

JB3888,0000E66-19-20140923