


## Heater and Air Conditioner Component Locations



TX1124562

### TX1124562-UN: Heater and Air Conditioner Component Location

**LEGEND:**

- 1 - Air Conditioner Compressor
- 2 - Compressor-to-Condenser Line
- 3 - Evaporator-to-Compressor Low Pressure Line
- 4 - Condenser
- 5 - Evaporator-to-Receiver-Dryer Line
- 6 - Receiver-Dryer
- 7 - Fresh Air Filter
- 8 - Heater and Air Conditioner Unit

9 - Heater Supply Line  
10 - Heater Return Line  
11 - Heater Coil  
12 - Evaporator Coil  
13 - Cab Recirculating Air Filter  
14 - Condenser-to-Receiver-Dryer High Pressure Line  
A4 - Sealed Switch Module (SSM)  
A7 - Automatic Temperature Control (ATC) Module  
M30 - Blend Air Door Motor  
M31 - Fresh Air Door Motor  
M32 - Mode Door Motor  
M33 - Blower Motor  
S30 - Air Conditioner Low Pressure Switch  
S31 - Air Conditioner High Pressure Switch  
S45 - Air Mode Control Switch  
S46 - Air Conditioner Switch—Manual Switch  
S47 - Automatic Temperature Control (ATC) Switch  
S50 - Blower Speed Increase Switch  
S51 - Air Recirculation Switch  
S52 - Temperature Increase Switch  
S55 - Blower Speed Decrease Switch  
S56 - Defrost Mode Switch  
S57 - Temperature Decrease Switch

[Go to Section\\_9031:Group\\_10](#)

DI77374,0000F04-19-20121025