



FRONT BRAKE MASTER CYLINDER



Order	Job name/Part name	Q'ty	Remarks
	Removing the front brake master cylinder		Remove the parts in the order listed.
	Drain the brake fluid		
1	Brake lever	1	
2	Front brake switch lead	2	
3	Front brake switch	1	
4	Union bolt	1	
5	Copper washers/brake hose	2/1	Refer to "REMOVING/INSTALLING THE FRONT BRAKE MASTER CYLINDER".
6	Master cylinder bracket	1	
7	Master cylinder	1	
			For installation, reverse the removal procedure.



Order	Job name/Part name	Q'ty	Remarks
	Disassembling the front brake master cylinder		Remove the parts in the order listed.
①	Dust boot	1	
②	Circlip	1	
③	Master cylinder cup	1	
④	Spring	1	
			For assembly, reverse the disassembly procedure.