
## FRONT WHEEL



Order	Job/Parts to remove	Q'ty	Remarks
1	Brake hose holder	1	
2	Reflector stay	2	
3	Reflector	2	
4	Front brake caliper	2	
5	Front wheel axle pinch bolt	1	Loosen.
6	Front wheel axle	1	
7	Collar	2	
8	Front wheel	1	
9	Front brake disc	2	
			For installation, reverse the removal proce- dure.

## **FRONT WHEEL**

Disassemb	bling the front wheel		
1 2			
Order	Job/Parts to remove	Q'ty	Remarks
1	Oil seal	2	
2	Wheel bearing	2	
3	Spacer	1	
			For assembly, reverse the disassembly pro- cedure.